

Temperatuur en luchtvochtigheid

Temperatuur en luchtvochtigheid

Temperatuur.jpg
The image cannot be displayed. Your computer may not have enough memory to open the image, or the image may have been deleted. Restart your computer and open the file again. If the red x still appears, you may have to delete the image and then insert it again.

DHT11

image.png
The image cannot be displayed. Your computer may not have enough memory to open the image, or the image may have been deleted. Restart your computer and open the file again. If the red x still appears, you may have to delete the image and then insert it again.

DHT11; van links naar rechts: *signaal* (naar port 2), *3.3V*, *GRND*.

Let op er zijn meerdere varianten en bij de meeste zit de data in het midden.

(<https://elektronicavoorjou.nl/product/dht11-temperatuur-en-vochtigheid-sensor/>)

Output

```
1
Temperature: 20.5 °C
Humidity: 45 %
2
Temperature: 20.5 °C
Humidity: 45 %
...
```

Code

```
#include <DHT.h>

#define DHTPIN 2      // Pin connected to the DHT11 data pin
#define DHTTYPE DHT11 // Specify DHT11 sensor
```

```
DHT dht(DHTPIN, DHTTYPE);
int count;

void setup() {
  Serial.begin(9600);
  dht.begin();
  count = 0;
  delay(5000);
}

void loop() {
  count++;
  delay(2000); // Wait 2 seconds between readings (DHT11 needs time)

  float temp = dht.readTemperature(); // Read temperature as a float
  int humidity = dht.readHumidity();

  if (isnan(temp)) {
    Serial.println("Failed to read from DHT sensor!");
  } else {
    Serial.println(count);

    Serial.print("Temperature: ");
    Serial.print(temp, 1);
    Serial.println(" °C");

    Serial.print("Humidity: ");
    Serial.print(humidity);
    Serial.println(" %");

    Serial.println("");
  }
}
```

Revision #5

Created 11 March 2025 18:59:35 by Max

Updated 11 March 2025 19:28:01 by Max